aerofoils | 0000

Screw Guide

Find the Right Fit for Your eFoil Setup

To make assembly easy and error-free, this overview shows you exactly which screws to use for each part of your Aerofoils setup. Match the components with the correct screw length — so you're ready to ride with confidence.

Screw Type: M6

| Component | Screw Length | Visualization |
|---|--|---------------|
| Mast | 20mm | |
| Stabilizer 510 Easyride Stabilizer 500 Easyride Stabilizer 400 Freeride Stabilizer 380 Freeride Stabilizer 300 Freerace Stabilizer 270 Freecarve | 20mm 20mm 20mm 20mm 20mm 20mm | |
| Wing 1750 easyride Wing 1350 Freeride Wing 1100 Freeride Wing 900 Freerace Wing 1250 Freecarve Wing 1000 Freecarve | 30mm 30mm 30mm 30mm 30mm 30mm | |
| Wing 2000 easyride | 35mm | |